

Hardware Diagram for rekordbox

■ CDJ-1500X



No.	CDJ-1500X	rekordbox	
		FUNCTION	+SHIFT
1	PLAY / PAUSE	Play / Pause	
2	CUE	Cue設定 / 再生, BackCue	曲頭へ移動
3	SHIFT	Shift	
4	BEAT LOOP	回す: Loop サイズ調整 押す: Auto Loop On / Off	Reloop
5	HOT CUE DELETE	HOT CUE Delete	
6	HOT CUE A	HOT CUE A設定 / 再生	HOT CUE A Delete
7	HOT CUE B	HOT CUE B設定 / 再生	HOT CUE B Delete
8	HOT CUE C	HOT CUE C設定 / 再生	HOT CUE C Delete
9	HOT CUE D	HOT CUE D設定 / 再生	HOT CUE D Delete
10	HOT CUE E	HOT CUE E設定 / 再生	HOT CUE E Delete
11	HOT CUE F	HOT CUE F設定 / 再生	HOT CUE F Delete
12	HOT CUE G	HOT CUE G設定 / 再生	HOT CUE G Delete
13	HOT CUE H	HOT CUE H設定 / 再生	HOT CUE H Delete
14	BACK	階層移動, エリア移動	
15	TAG TRACK / REMOVE	Tag Listへの登録, 解除	
16	ROTARY SELECTOR	回す: Browse (Select Track / Folder) 押す: 階層移動 / 曲Load	
17	TEMPO	テンポ調整	
18	JOG DIAL (天面)	スクラッチ (Vinyl On) ピッチベンド (Vinyl Off)	Search
19	JOG DIAL (側面)	ピッチベンド	



	LOOP	-
	LOOP IN	Loop In / ループ再生中: Loop In Adjustment
	LOOP OUT	Loop Out / ループ再生中: Loop Out Adjustment
20	RELOOP / EXIT	Reloop / Exit
	BEAT LOOP 1/2, 1, 2, 4, 8, 16	Beat Loop 1/2, 1, 2, 4, 8, 16
	BEAT LOOP 3/4, 1, 3/2, 3, 5, 7	Beat Loop 3/4, 1, 3/2, 3, 5, 7
	SLIP LOOP	Slip Loop 1/8, 1/4, 1/2, 1, 1/3, 3/4 *1
	SLIP REVERSE	Slip Reverse
21	NEEDLE POSITION (全体波形)	Needle Search
	MEMORY CUE	-
22	CUE / LOOP CALL NEXT / PREV	Cue / Loop Call
	CUE / LOOP DELETE	Cue / Loop Delete
	CUE / LOOP MEMORY	Cue / Loop Memory
	BEAT JUMP	-
23	BEAT JUMP FWD / REV (1/2),(1),(2),(4)	Beat Jump Fwd / Rev (1/2),(1),(2),(4)
	BEAT JUMP FWD / REV (8),(16),(32),(64)	Beat Jump Fwd / Rev (8),(16),(32),(64)
24	SLIP	Slip On / Off
25	QUANTIZE	Quantize On / Off
26	TEMPO RANGE	Tempo Range
27	MASTER TEMPO	Master Tempo On / Off
28	SYNC	Sync On / Off 長押し: INSTANT DOUBLES
29	MASTER	Master
30	VINYL SPEED ADJUST ON / OFF	No function assigned here
	VINYL SPEED ADJUST (GUI / SHORTCUT)	Vinyl Speed Adjust (Touch / Release)
31	JOG MODE	Vinyl On / Off

*1: rekordbox側では、BEAT LOOPの拍数が変化します。